## 3. Correction of camera image (Optional)

If the camera image is upside down. As shown in the figure:




Then you need to set the camera screen. The steps are as follows:

- 1. First put the SET\_Camera.py in the data under the Linux system, anywhere
- 2. Then open the terminal in the directory with SET\_Camera.py and run the command

python3 SET\_Camera.py

3. In the terminal, enter the IP address obtained by starting the proxy terminal (the command to start the proxy, see **2. Connect to the ROS-wifi image transmission module proxy**), and press Enter



4. When **Camera is set ok!** appears The camera image is reversed

If Camera is set ok! does not appear for a long time, check whether the IP address you entered is correct.



(x=391, v=471) ~ R:13 G:50 B:136